Installing Hardware Drivers

(Excerpt from the Pro Tools Software Installation Guide Version 9.0)

Before installing Pro Tools software, ensure that you have installed your audio hardware and that you have installed the latest drivers for your hardware. Refer to the documentation that came with your hardware for more information. For Avid audio interfaces, visit www.avid.com to download and install the latest drivers for your device.

Driver Downloads and Updates for Pro Tools 9
The latest drivers are available from the following page:

- www.avid.com/drivers

Pro Tools will not recognize your audio interface if you do not install the drivers. If you are upgrading your Pro Tools system, be sure to install the most current drivers for your hardware.

For Pro Tools|HD and Pro Tools|HD Native systems only, the Pro Tools installer installs the necessary hardware drivers automatically.

For detailed information about installing ProTools|HD hardware, see the Pro Tools|HD User Guide. For detailed information about installing Pro Tools|HD Native hardware, see the Pro Tools|HD Native User Guide.